

CD/DVD Cleaner

Description:

CD/DVD/LP cleaner is ideal for removing dirt, fingerprints and other particles to get optimal play from your CDs, DVDs and vinyl records (LP singles etc.). It also prolongs the performance and longevity of your CD/DVD-ROM drive or CD/DVD/LP player by keeping the laser clean.


Instructions of use: Apply a small amount of the spray to the surface to be cleaned and wipe gently with a soft clean cloth, preferably micro fiber cloth.

CLASSIFICATION:

- Extremely flammable
- Irritant
- Dangerous for the environment

CAN SPECIFICATION:

- 200 ml Tinplate can
- Diameter 52*132



CAUTION:

Irritating to eyes and skin. Toxic to aquatic organisms, may cause long-term adverse effects in the aquatic environment. Repeated exposure may cause skin dryness or cracking. Vapours may cause drowsiness and dizziness. Pressurized container. Protect from sunlight and do not expose to temperatures exceeding 50 C. Do not pierce or burn, even after use. Do not spray on a naked flame or any incandescent material. Keep out of the reach of children. Keep away from sources of ignition. No smoking. Do not breathe spray. Avoid contact with skin and eyes. In case of contact with eyes, rinse immediately with plenty of water and seek medical advice. Use only in well-ventilated areas.

DETERGENT DIRECTIVES:

30 and more aliphatic hydrocarbons

LIST OF INGREDIENTS :

Isopropyl Alcohol

Pentane

Butane

Propane

Each ingredient is described by its INCI name (International Nomenclature of Cosmetic Ingredients; see also <http://www.edqm.eu/site/Work-ProgrammeStatus-607.html> or

<http://ecb.jrc.ec.europa.eu/esis/> or if no INCI name is available, then the ingredient is described by its common name or IUPAC name (International Union of Pure and Applied Chemistry).

